



Stainless Steel Drop Visors

Peterbilt

Part Number
7800

12" Peterbilt drop visor for models: 359, 1967-1986.



Part Number
7805

14" Peterbilt drop visor for models: 377, 378, 379. Pre-2005 Standard-cab with door mounted mirrors.



Part Number
7810

14" Peterbilt drop visor for models: 377, 378, 379. 1996-2001 ultra-cab.



Part Number
7815

14" Peterbilt drop visor for models: 377, 378, 379. 2002-2008 ultra-cab with door mounted mirrors.

Part Number
7820

14" Peterbilt drop visor for models: 377, 378, 379. 2005 - Newer ultra-cab with cab mounted mirrors.



Mounting hardware included.



Kenworth

Part Number
7825

13" Kenworth drop visor for models: W900 and T800. 1995-2008 Aerocab curved windshield.



Part Number
7830

13" Kenworth drop visor for models: W900 and T800. 1984-1998 cabs with a split flat windshield.



Mounting hardware included.

Freightliner

Part Number
7835

18" Freightliner drop visor for models with raised-roof style cab/sleeper. With 9 cutouts for 2" lights.

Part Number
7845

18" Freightliner drop visor for models with mid-roof style cab/sleeper. With 9 cutouts for 2" lights.



Does not fit Columbia

Part Number
7840

18" Freightliner drop visor for models with raised-roof style cab/sleeper. With 8 pre-drilled holes for 4" bolt pattern lights.

Part Number
7850

18" Freightliner drop visor for models with mid-roof style cab/sleeper. With 8 pre-drilled holes for 4" bolt pattern lights.



Mounting hardware included.