

ABS Axle Covers Push-on Style



Not enough thread? No problem!

Roadmaster has ABS axle covers for use with 33mm short studs and 1-1/2" lug nuts

Remove two lug nuts from the wheel on opposite sides

Place the rim protector, followed by the ABS axle cover, over the existing lug nuts

Place the supplied retainer rings opposite of each other, then replace the lug nuts; torque the nuts as usual Install push-on nut covers to complete the installation



217S-3



Part Number

217P-111PFLPN



33mm x 2-3/4"

Part Number

344P-111PFLPN



33mm x 2-3/4"



ABS Axle Covers Push-on Style

Front Axle Covers

Part Number

217P-110P



Part Number

217P-110PP



Part Number

217P-110XTP



Part Number

217P-112P



Rear Axle Covers

Part Number

344P-110P



Part Number

344P-110PP



Part Number

344P-110XTP



Part Number

344P-112P



1-1/2" x 2-1/4"



1-1/2" X 4-1/4"



1-1/2" X 3-1/8"



33mm x 3-1/16"