

LED Lights




Stop Turn and Tail Lights



1907-2AC

1907-2RC



1911-1A

1911-1R



1911-2AC

1911-2RC



1915-30A


1915-30R

Part Number	Clear Lens Option	LEDs	Color	Light Size	Features	Measurements	Connection Type	Carded
	1907-2AC	7	Amber	4"	Stop, Turn, and Tail Light	4-1/4" x 2-5/16"	3 Prong	✓
	1907-2RC	7	Red	4"	Stop, Turn, and Tail Light	4-1/4" x 2-5/16"	3 Prong	✓
1911-1A	1911-2AC	12	Amber	4"	Stop, Turn, and Tail Light	4-1/4" x 2-5/16"	3 Prong	✓
1911-1R	1911-2RC	12	Red	4"	Stop, Turn, and Tail Light	4-1/4" x 2-5/16"	3 Prong	✓
1911CD-A		12	Amber	4"	Grommet and Pigtail included	4-1/4" x 2-5/16"	3 Prong	✓
1911CD-R		12	Red	4"	Grommet and Pigtail included	4-1/4" x 2-5/16"	3 Prong	✓
1915-30A		30	Amber	4"	Stop, Turn, and Tail Light	4-1/4" x 2"	3 Prong	✓
1915-30R		30	Red	4"	Stop, Turn, and Tail Light	4-1/4" x 2"	3 Prong	✓
1915CD-2A		30	Amber	4"	Grommet and Pigtail included	4-1/4" x 2"	3 Prong	✓
1915CD-2R		30	Red	4"	Grommet and Pigtail included	4-1/4" x 2"	3 Prong	✓




1920-1A

1920-1R



1919-1R

1919-1A



1919-2RC

1919-2AC

Part Number	Clear Lens Option	LEDs	Color	Light Size	Features	Measurements	Connection Type	Carded
1920-1A		21	Amber	5-1/4"	Stop, Turn, and Tail Light	5-1/4" X 3-7/16" X 1-15/16"	3 Prong	✓
1920-1R		15	Red	5-1/4"	Stop, Turn, and Tail Light	5-1/4" X 3-7/16" X 1-15/16"	3 Prong	✓
1920CD-A		21	Amber	5-1/4"	Grommet and Pigtail included			✓
1920CD-R		15	Red	5-1/4"	Grommet and Pigtail included			✓
1919-2A	1919-2AC	14	Amber	6-1/2"	Stop, Turn, and Tail Light	6-1/2" x 2-1/4" x 2-1/4"	3 Prong	✓
1919-2R	1919-2RC	14	Red	6-1/2"	Stop, Turn, and Tail Light	6-1/2" x 2-1/4" x 2-1/4"	3 Prong	✓
1919CD-A		14	Amber	6-1/2"	Stop, Turn, and Tail Light		3 Prong	✓
1919CD-R		14	Red	6-1/2"	Stop, Turn, and Tail Light		3 Prong	✓